



## Seleccione su Equipo MARDAL

Vivienda	Nº de Baños Máximo	Tanque, Galones	Presion (PSI)	Potencia (HP)	Modelo
----------	-----------------------	--------------------	------------------	------------------	--------

Apartamentos, Consultorios Médicos, Casas de Playa (1 nivel)	1	20	20-40	1/2	HSP o PSM 50/20 Gls
		35	20-40	1/2	PSM 50/35 Gls
	2	40	20-40	1/2	HSP o PSM 50/40 Gls
		35	20-40	3/4	PSM 75/35 Gls
		40	20-40	3/4	HSP 75/40 Gls

CASA (1 nivel)	2	40	20-40	1	ITM o HSP o EHV-MAX 100/40 Gls
		70	20-40	3/4	PSM 75/70 Gls
	4	70	20-40	1	PSM 100/70 Gls
		80	20-40	1	ITM o EHV-MAX 100/80 Gls
	5	80	20-40	1	ITM o EHV-MAX 100/80 Gls
		100	20-40	1	PSM 100/100 Gls
6	120	20-40	1	ITM o EHV-MAX o DPX 100/120 Gls	

CASA (2 niveles)	2	80	30-50	1	ITM o EHV-MAX 100/80 Gls
		100	30-50	1	PSM 100/100 Gls
	5	120	30-50	1	ITM o EHV-MAX o DPX 100/120 Gls
	6	120	30-50	1.5	ITM o EHV-MAX o DPX 150/120 Gls

CASA (3 niveles)	2	120	30-50	2	EHV-MAX o DPX 200/120 Gls
	4	120	30-50	2	EHV-MAX o DPX 200/120 Gls
		120	30-50	2.2	ITM 200/120 Gls
	5	150	30-50	2	EHV-MAX o DPX 200/150 Gls
		150	30-50	2.2	ITM 200/150 Gls
	6	150	30-50	3	EHV-MAX o DPX 300/150 Gls

### Otras Edificaciones

3 Niveles	hasta 75 piezas	220	30-50	3	EHV-MAX o DPX 300/220 Gls
4 Niveles	hasta 120 piezas	220	40-60	5	EHV-MAX o DPX 500/220 Gls
		300	40-60	5	EHV-MAX 500/300 Gls

Para otras configuraciones consultar.